

# Industrial Style Dart Holder

UPC 197644845835 (Texas Star Version)

UPC 197644066322 (Championship Version)

Thank you for purchasing your new Industrial Dart Holder. We're confident that you'll be happy with your purchase, but in the event that something is missing or there is a manufacturing defect or damage, please contact us at [admin@nplabs.ca](mailto:admin@nplabs.ca).

This dart holder is the first of its kind. It solves the problem with having your darts perfectly aligned, has dart holes that are at a much more convenient 45 degree angle, is front mounted, can hold 5 sets of darts and since it comes in two optional metallic finishes, there is no need to try to match it to other wood tones you may have.

If you are happy with your new dart holder, please help us by giving this product a 5 star review. Thank you and enjoy your new dart holder!

## Product Contents

- Industrial Style Dart Holder
- Universal Contractor Mounting Hardware (2 Phillips Screws and 2 wall anchors)

## How to Mount

### Tools Needed

- 1/4" standard drill bit (if mounting to drywall)
- 3/16" masonry bit (if mounting to concrete or brick)
- Drill (you will need a hammer drill if mounting to concrete or brick)
- Phillips Screwdriver
- Pencil
- Hammer

### Marking and Mounting

1. Hold the dart holder against the wall where you wish to mount it and trace the top and bottom iron flange holes onto your wall.
2. **If your wall is Drywall:** Drill holes in the center of the holes you traced on your wall using a 1/4" drill bit. **Important! Ensure there is no electrical wire or water pipe where you will be drilling. We recommend drilling just beyond the depth of the drywall (usually 1/2"), then check that there is at least 1" of free space behind the drywall with your screwdriver.** If you detect a wooden stud, you can screw the dart holder through the drywall and into the stud. 1/8" pilot holes may be required if the screws are too difficult to turn. If there is no stud, press fit or tap in a wall anchor in each hole until they are flush with the wall surface.
3. **If your wall is Concrete or Brick:** Drill holes in the center of the circles you traced on your wall using a 3/16" masonry drill bit using a hammer drill. Ensure the holes are as deep as the length of the provided screws. Next, press fit or tap in a wall anchor in each hole until they are flush with the wall surface.
4. Hold the dart holder against the wall so that the holes are aligned then use a Phillips screwdriver to screw in the screws.

Note: In the future, if you ever wish to refurbish the black dart entry plates, you can resurface them with a green Scotchbrite pad by scrubbing them horizontally to remove fine scratches and restore the brushed appearance.

